HAMPTONS FENCE SOLAR LIGHT

INSTALLATION OVERVIEW

Press button to toggle ON/OFF

Cover sensor/solar panel area on top of light to test light


TIP Before starting installation, ensure light is switched on. Press the button on the underside of the light and cover the sensor/solar panel on the top of the light.

If light does not illuminate, press button again and repeat process.

If light does not turn on a second time, consider leaving cap in the sun to charge for several hours before trying again.

If light fails to illuminate after charging, consider replacing batteries and charging before testing again.

1 Insert solar light into top of open post.

2 Align screw and self tapping screw and cover-cap with hole in solar light. Using a drill, screw through hole into post.
Repeat on opposite side.

3 Close cover over caps to hide screw heads and finish.